

## Supported Camera List

AXIS cameras running firmware version 6.50 or newer are supported for Latch Intercom video calls. The following cameras are supported as of January 30, 2020. This list is to be used for reference only. Individual camera support should be verified with the reseller.

[AXIS Companion 360](#)

[AXIS Companion Bullet LE](#)

[AXIS Companion Bullet mini LE](#)

[AXIS Companion Cube L](#)

[AXIS Companion Cube LW](#)

[AXIS Companion Dome mini LE](#)

[AXIS Companion Dome V](#)

[AXIS Companion Dome WV](#)

[AXIS Companion Eye L](#)

[AXIS Companion Eye LVE](#)

[AXIS Companion Eye mini L](#)

[AXIS Companion Recorder 4CH](#)

[AXIS Companion Recorder 8CH](#)

[AXIS D2050-VE](#)

[AXIS F34 Main Unit](#)

[AXIS F41 Main Unit](#)

[AXIS F44 Dual Audio Input](#)

[AXIS F44 Main Unit](#)

[AXIS FA54 Main Unit](#)

[AXIS M1045-LW](#)

[AXIS M1065-L](#)

[AXIS M1065-LW](#)

[AXIS M1124](#)

[AXIS M1124-E](#)

[AXIS M1125](#)

[AXIS M1125-E](#)

[AXIS M1134](#)

[AXIS M1135](#)

[AXIS M1135-E](#)

[AXIS M1137](#)

[AXIS M1137-E](#)

[AXIS M1145](#)

[AXIS M1145-L](#)

[AXIS M2025-LE](#)

[AXIS M2026-LE](#)

[AXIS M2026-LE Mk II](#)

[AXIS M3006-V](#)

[AXIS M3007-P](#)

[AXIS M3007-PV](#)

[AXIS M3015](#)

[AXIS M3016](#)

[AXIS M3026-VE](#)

[AXIS M3027-PVE](#)

[AXIS M3037-PVE](#)

[AXIS M3044-V](#)

[AXIS M3044-WV](#)

[AXIS M3045-V](#)

[AXIS M3045-WV](#)

[AXIS M3046-V 1.8 mm](#)

[AXIS M3046-V 2.4 mm](#)

[AXIS M3047-P](#)

[AXIS M3048-P](#)

[AXIS M3057-PLVE](#)

[AXIS M3058-PLVE](#)

[AXIS M3104-L](#)

[AXIS M3104-LVE](#)

[AXIS M3105-L](#)

[AXIS M3105-LVE](#)

[AXIS M3106-L](#)

[AXIS M3106-L Mk II](#)

[AXIS M3106-LVE](#)

[AXIS M3106-LVE Mk II](#)

[AXIS M3205-LVE](#)

[AXIS M3206-LVE](#)

[AXIS M4206-LV](#)

[AXIS M4206-V](#)

[AXIS M5054](#)

[AXIS M5055](#)

[AXIS M5065](#)

[AXIS M5525-E](#)

[AXIS M7011](#)

[AXIS M7104](#)

[AXIS P1244](#)

[AXIS P1245](#)  
[AXIS P1254](#)  
[AXIS P1264](#)  
[AXIS P1265](#)  
[AXIS P1275](#)  
[AXIS P1280-E](#)  
[AXIS P1290-E](#)  
[AXIS P1353](#)  
[AXIS P1353-E](#)  
[AXIS P1354](#)  
[AXIS P1354-E](#)  
[AXIS P1357](#)  
[AXIS P1357-E](#)  
[AXIS P1364](#)  
[AXIS P1364-E](#)  
[AXIS P1365](#)  
[AXIS P1365 Mk II](#)  
[AXIS P1365-E](#)  
[AXIS P1365-E Mk II](#)  
[AXIS P1367](#)  
[AXIS P1367-E](#)  
[AXIS P1368-E](#)  
[AXIS P1375](#)  
[AXIS P1375-E](#)  
[AXIS P1377](#)  
[AXIS P1377-LE](#)  
[AXIS P1378](#)  
[AXIS P1378-LE](#)  
[AXIS P1405-E](#)  
[AXIS P1405-LE](#)  
[AXIS P1405-LE Mk II](#)  
[AXIS P1425-E](#)  
[AXIS P1425-LE](#)  
[AXIS P1425-LE Mk II](#)  
[AXIS P1427-E](#)  
[AXIS P1427-LE](#)  
[AXIS P1428-E](#)  
[AXIS P1435-E](#)  
[AXIS P1435-LE](#)

[AXIS P1445-LE](#)  
[AXIS P1445-LE-3](#)  
[AXIS P1447-LE](#)  
[AXIS P1448-LE](#)  
[AXIS P3214-V](#)  
[AXIS P3214-VE](#)  
[AXIS P3215-V](#)  
[AXIS P3215-VE](#)  
[AXIS P3224-LV](#)  
[AXIS P3224-LV Mk II](#)  
[AXIS P3224-LVE](#)  
[AXIS P3224-LVE Mk II](#)  
[AXIS P3224-V Mk II](#)  
[AXIS P3224-VE Mk II](#)  
[AXIS P3225-LV](#)  
[AXIS P3225-LV Mk II](#)  
[AXIS P3225-LVE](#)  
[AXIS P3225-LVE Mk II](#)  
[AXIS P3225-V Mk II](#)  
[AXIS P3225-VE Mk II](#)  
[AXIS P3227-LV](#)  
[AXIS P3227-LVE](#)  
[AXIS P3228-LV](#)  
[AXIS P3228-LVE](#)  
[AXIS P3235-LV](#)  
[AXIS P3235-LVE](#)  
[AXIS P3245-LV](#)  
[AXIS P3245-LVE](#)  
[AXIS P3245-V](#)  
[AXIS P3245-VE](#)  
[AXIS P3353](#)  
[AXIS P3354](#)  
[AXIS P3363-V](#)  
[AXIS P3363-VE](#)  
[AXIS P3364-LV](#)  
[AXIS P3364-LVE](#)  
[AXIS P3364-V](#)  
[AXIS P3364-VE](#)  
[AXIS P3365-V](#)

[AXIS P3365-VE](#)  
[AXIS P3367-V](#)  
[AXIS P3367-VE](#)  
[AXIS P3374-LV](#)  
[AXIS P3374-V](#)  
[AXIS P3375-LV](#)  
[AXIS P3375-LVE](#)  
[AXIS P3375-V](#)  
[AXIS P3375-VE](#)  
[AXIS P3384-V](#)  
[AXIS P3384-VE](#)  
[AXIS P3707-PE](#)  
[AXIS P3717-PLE](#)  
[AXIS P3719-PLE](#)  
[AXIS P3807-PVE](#)  
[AXIS P3904-R](#)  
[AXIS P3904-R Mk II](#)  
[AXIS P3905-R](#)  
[AXIS P3905-R Mk II](#)  
[AXIS P3905-RE](#)  
[AXIS P3915-R](#)  
[AXIS P3915-R Mk II](#)  
[AXIS P5414-E](#)  
[AXIS P5415-E](#)  
[AXIS P5514](#)  
[AXIS P5514-E](#)  
[AXIS P5515](#)  
[AXIS P5515-E](#)  
[AXIS P5624-E](#)  
[AXIS P5624-E Mk II](#)  
[AXIS P5635-E](#)  
[AXIS P5635-E Mk II](#)  
[AXIS P5655-E](#)  
[AXIS P7304](#)  
[AXIS P8535](#)  
[AXIS P8804](#)  
[AXIS P9106-V](#)  
[AXIS Q1604](#)  
[AXIS Q1604-E](#)

[AXIS Q1614](#)  
[AXIS Q1614-E](#)  
[AXIS Q1615](#)  
[AXIS Q1615 Mk II](#)  
[AXIS Q1615-E](#)  
[AXIS Q1615-E Mk II](#)  
[AXIS Q1635](#)  
[AXIS Q1635-E](#)  
[AXIS Q1645](#)  
[AXIS Q1645-LE](#)  
[AXIS Q1647](#)  
[AXIS Q1647-LE](#)  
[AXIS Q1659](#)  
[AXIS Q1700-LE](#)  
[AXIS Q1765-LE](#)  
[AXIS Q1765-LE PT Mount](#)  
[AXIS Q1775](#)  
[AXIS Q1775-E](#)  
[AXIS Q1785-LE](#)  
[AXIS Q1786-LE](#)  
[AXIS Q1798-LE](#)  
[AXIS Q1931-E](#)  
[AXIS Q1931-E PT Mount](#)  
[AXIS Q1932-E](#)  
[AXIS Q1932-E PT Mount](#)  
[AXIS Q1941-E](#)  
[AXIS Q1941-E PT Mount](#)  
[AXIS Q1942-E](#)  
[AXIS Q1942-E PT Mount](#)  
[AXIS Q2901-E](#)  
[AXIS Q2901-E PT Mount](#)  
[AXIS Q3504-V](#)  
[AXIS Q3504-VE](#)  
[AXIS Q3505-SVE Mk II](#)  
[AXIS Q3505-V](#)  
[AXIS Q3505-V Mk II](#)  
[AXIS Q3505-VE](#)  
[AXIS Q3505-VE Mk II](#)  
[AXIS Q3515-LV](#)

[AXIS Q3515-LVE](#)  
[AXIS Q3517-LV](#)  
[AXIS Q3517-LVE](#)  
[AXIS Q3517-SLVE](#)  
[AXIS Q3518-LVE](#)  
[AXIS Q3527-LVE](#)  
[AXIS Q3615-VE](#)  
[AXIS Q3617-VE](#)  
[AXIS Q3708-PVE](#)  
[AXIS Q6000-E](#)  
[AXIS Q6000-E Mk II](#)  
[AXIS Q6042](#)  
[AXIS Q6042-C](#)  
[AXIS Q6042-E](#)  
[AXIS Q6042-S](#)  
[AXIS Q6044](#)  
[AXIS Q6044-C](#)  
[AXIS Q6044-E](#)  
[AXIS Q6044-S](#)  
[AXIS Q6045 Mk II](#)  
[AXIS Q6045-C Mk II](#)  
[AXIS Q6045-E Mk II](#)  
[AXIS Q6045-S Mk II](#)  
[AXIS Q6052](#)  
[AXIS Q6052-E](#)  
[AXIS Q6054](#)  
[AXIS Q6054 Mk II](#)  
[AXIS Q6054 Mk III](#)  
[AXIS Q6054-E](#)  
[AXIS Q6054-E Mk II](#)  
[AXIS Q6054-E Mk III](#)  
[AXIS Q6055](#)  
[AXIS Q6055-C](#)  
[AXIS Q6055-E](#)  
[AXIS Q6055-S](#)  
[AXIS Q6074](#)  
[AXIS Q6074-E](#)  
[AXIS Q6075](#)  
[AXIS Q6075-E](#)

[AXIS Q6114-E](#)

[AXIS Q6115-E](#)

[AXIS Q6124-E](#)

[AXIS Q6125-LE](#)

[AXIS Q6128-E](#)

[AXIS Q6154-E](#)

[AXIS Q6155-E](#)

[AXIS Q6215-LE](#)

[AXIS Q7411](#)

[AXIS Q7436 Blade](#)

[AXIS Q8414-LVS](#)

[AXIS Q8631-E](#)

[AXIS Q8632-E](#)

[AXIS Q8641-E](#)

[AXIS Q8642-E](#)

[AXIS Q8665-E](#)

[AXIS Q8665-LE](#)

[AXIS Q8685-E](#)

[AXIS Q8685-LE](#)

[AXIS Q8741-E](#)

[AXIS Q8741-LE](#)

[AXIS Q8742-E 35 mm 8.3 fps 24 V](#)

[AXIS Q8742-E Zoom 30 fps 24 V](#)

[AXIS Q8742-E Zoom 8.3 fps 24 V](#)

[AXIS Q8742-LE 35 mm 8.3 fps 24 V](#)

[AXIS Q8742-LE Zoom 30 fps 24 V](#)

[AXIS Q8742-LE Zoom 8.3 fps 24 V](#)

[AXIS T8508 PoE+ Network Switch](#)

[AXIS T8516 PoE+ Network Switch](#)

[AXIS T8524 PoE+ Network Switch](#)

[AXIS V5914](#)

[AXIS V5915](#)

[D101-A XF P3807](#)

[D201-S XPT Q6055](#)

[ExCam XF M3016](#)

[ExCam XF P1367](#)

[ExCam XF Q1645](#)

[ExCam XF Q1785](#)

[ExCam XPT Q6055](#)



[F101-A XF P1367](#)

[F101-A XF Q1785](#)

[XF40-Q1765](#)

[XF40-Q2901](#)

[XF60-Q1765](#)

[XF60-Q2901](#)

[XP40-Q1765](#)

[XP40-Q1942](#)